

# PC Game Pad

Congratulations on purchasing the Cyber Snipa™ Game Pad. The Game Pad has been designed to work with most PC First Person Shooter (FPS) Games. Please read the following instructions carefully to ensure optimal use.



## OPTIMIZE YOUR GAMING

The Cyber Snipa™ Game Pad is the first of its kind – a unique keypad, optimized for FPS Gaming. It's easy to use, intuitive key layout ensures easy key placement in order that you can get started within a matter of minutes.

Now you can optimize your gaming workspace by positioning the Game Pad along side your mouse and mouse pad, in a far more flexible way. In no time at all, you will feel like this Game Pad has been made specifically for you and with practice your game control, speed and accuracy will improve.

## GETTING STARTED

The Cyber Snipa™ Game Pad has been designed to work along side your normal keyboard, you simply move your standard keyboard aside and position the Game Pad alongside your mouse and mouse pad.

- Plug the USB adaptor into a free port on your PC
- The device should immediately be recognised in Windows XP, 2000, and Windows Me, therefore no drivers are required
- The keys depicted on the Game Pad are defaulted to the keys on a standard keyboard needed for most FPS Games

Your existing FPS movement and action keyboard keys will already be mapped on the Game Pad. If you need to change any key mapping, you can configure commands to keys on the Game Pad by:

- Start the Game on your PC
- Select the options tab (may differ from game to game)
- Find the key mapping window and select and program the keys that are required
- Exit the options window and play!

## LED UNDER CASE LIGHTING

You will notice a small push button switch on the right hand side of the Game Pad. Simply push the switch in to activate the blue LED under case lights. Push again in order to turn them off. The pin hole LED, located under the F2/F3 keys remains illuminated if the Game Pad is connected to the PC.

**LIMITED WARRANTY** Flexiglow Hong Kong warrants that the hardware you have purchased from Flexiglow Hong Kong or from a Flexiglow authorised dealer is free from manufacturer defects. The warranty period is 6 months from date of purchase. If you can demonstrate that there is a defect in workmanship or material during the warranty period, Flexiglow Hong Kong at its option will replace or repair the device or any component thereof. The Limited Warranty only applies to the original purchaser. An original, dated sales receipt is the sole proof of purchase. The warranty is voided if you are unable to present the dated sales receipt.

**HEALTH WARNING** Using a keyboard for an extended period of time may cause serious injury or disorders. If you experience any persistent pain or discomfort, do not ignore these signs. Limit your use of the device and consult a qualified health professional.

**COMPLIANCE** This device has been tested to comply with FCC standards for home and office use.

**Cyber  
Snipa™**

Flexiglow Hong Kong, B/D IF, Gee Hing Ind Bldg.  
16 Cheung Yue St. Lai Chi Kok, Kowloon, Hong Kong  
Tel:+61 2 9684 6796 • Fax:+61 2 9638 4811 • [www.cybersnipa.com](http://www.cybersnipa.com)

© 2005 Flexiglow Hong Kong. All rights reserved. Flexiglow™ and Cyber Snipa™ are registered trademarks of Flexiglow. U.S. and International Patents Pending.